


PLEASE NOTE: When using 3-wire sensor, operation of DLC-PCC is reversed from labelling on unit. Use N.C. connection and setpoints as shown.

**DLC-PCC with Power Pack**



**Building Automation, Inc.**